

**4. DNC-Interface**  
**RS 232-Interface**

**DNC-Interface:**

- DNC-Interface (Compact 5 CNC)..... 4/1
- DNC-Interface (PIN-Coverage SW-A6C 114 004) ..... 4/2
- Function of the DNC-board..... 4/3.1-4/3.3
- Mounting of the DNC-board ..... 4/4.1-4/4.2

**RS 232 Interface:**

- G66-RS 232 Operation ..... 4/5
- Survey RS 232 Operation ..... 4/6
- RS 232c-Connection cable for Compact 5 CNC  
and F1 CNC ..... 4/7.1-4/7.3
- Video Connection, TV-Connection Interface  
RS 232 ..... 4/8.1-4/8.3
- Pinning of Compact 5 CNC ..... 4/8.4-4/8.5
- RS 232 Connection/Some Tips ..... 4/8.6-4/8.8
- Data Formats COMPACT 5 CNC  
Software A6C 114 004 ..... 4/9
- Service Information Turret Toolpost ..... 4/10

## DNC-Interface

(Compact 5 CNC)

The DNC-interface is an accessory which can be built in at later stage on request. The DNC-interface allows to send instructions with the help of a CNC-program.

### Attention:

If you use the DNC-interface together with external voltage sources you have to obey the maximum power and voltage values. Also differences in the potential between the devices have to be taken into account. An excessive voltage at an DNC-input or output can destroy the complete electronics of the Compact 5 CNC.

DNC-Interface

## PIN - Coverage

X62/PIN	1	A	Status hand
	2	E	Turret - hand operation
	3	E	Instruction G66 + INP
	4	-	-
	5	-	-
	6	E	Instruction G66 + FWD
	7	A	Status program running
	8	A	Status intermediate stop
	9	E	Instruction switch hand /CNC
	10	-	-
	11	-	-
	12	-	-
	13	-	-
	14	-	-
	15	A	Output set with M8, M9
	16	-	-
	17	E	Instruction start
	18	A	Output set with M22, M23
	19	A	Status main motor ON/OFF
	20	A	Output impulse set with M26
	21	E	Instruction blockage-turret
	22	V	+10V not controlled
	23	V	} GND
	24	V	
	25	V	
	26	V	+5V controlled

E = Input  
A = Output  
V = Power

## Function of the DNC-board:

1.

- The main spindle can be switched on with M03 and switched off with M05 (set main spindle switch to CNC).
  
- A main spindle switched on with M03, can be switched off manually during the intermediate stop, by actuating the M-switch (e.g. for measuring processes). Where the intermediate stop is interrupted by a start, the main spindle is automatically switched on again, and after a 2 second start delay, the program continues to operate.
  
- The program end command M30, automatically produces a switching off of the main spindle (additional programming of M05 is not necessary).

2.

In and output possibilities of the DNC-interface via the 26-pole plug X62:

### A) Outputs:

PIN 1: Status Hand

The machine reports whether it is in Hand or CNC-operation:

PIN 1 with CNC-operation ....LO

PIN 1 with Hand-operation ...HI

PIN 7: Status program running.

The machine reports, whether a program is worked off at the moment.

Program running .....HI

Program not running .....LO

PIN 8: Status intermediate stop

The machine reports whether it is in intermediate stop or not.

Intermediate stop .....HI

No intermediate stop .....LO

PIN 15 - Output set M08, M09

PIN 18 - Output set M08, M09

Input of	produces at switch output / Pin	the condition	initial condition
M08 M09	X 62 / 15 X 62 / 15	HI LO	LO
M22 M23	X 62 / 18 X 62 / 18	HI/ LO	LO

These 3 switch outputs can also be manually actuated.

Lighting the WEG-LED	and actuating the pushbutton	produces at switch output / Pin	the condition
X X	FWD REV	X 62 / 15 X 62 / 15	HI LO
Z Z	FWD REV	X 62 / 18 X 62 / 18	HI LO

With Pin 19, the main motor is switched on and off.

M03 - HI

M05 - LO

Initial condition - LO

Pin 20: Pulse output

Format M 26 N3/M26/H3
--------------------------

At Pin 20, with a frequency of 100 Hz, the number of pulses given with H is issued (HI-LO).

Initial condition: LO

Maximum H-input: 0-221

The program is interrupted during the output time, and is then subsequently continued.

#### B) Inputs:

Where a voltage of 3 - 30 V is applied to the following pins, the following functions are executed by the machine:

Pin 2: Turret - HAND operation

Pin 3: Set the machine to RS-232 operation (received as with G66 + INP)

Pin 6: Set the machine to RS-232 operation (transmit as G66 + FWD)

Pin 9: Change machine from manual operation to CNC operation, or vice versa.

PIN 17: Through voltage at PIN 17 a start instruction is effected.  
PIN 17 is not cabled to the CPU board.  
Compare also notes with cabling.

PIN 21: Instruction turret blockage.

C) Power:

PIN 22: + 10V not controlled


PIN 23:

PIN 24: GND



PIN 25:

PIN 26: + 5 V controlled

Example entrance:



Example exit:



3. To plug X64/PIN 5,6 an opener contact can be connected, with same function as X62/PIN 10 (e.g. function end guard of door).  
h3 lights up when door is open (J4).

Mounting of the DNC-Interface:Scope of supply


1. PC-board
2. Cable 16 - 12-pole
3. Cable 5-pole
4. Cable 2-pole
5. Spacer bolt with washers
6. Cable clips
7. Relay

Work to be carried out:

- Assemble DNC-board
- Connect all cables

Attention:

- Disconnect the mains plug prior to carrying out all assembly work. Otherwise there is not only the danger of accident, but also the danger of electronic components on the boards being destroyed.
- Never connect and switch on the machine, when all the plug connections are not fitted and the printed circuit boards are not fastened. Loose cables and printed circuit boards cause short-circuits, when they come into contact with the housing or other pc-boards.

Assembly of the DNC-board


- Replace the cylinder bolts on the cassette board with spacer bolts (1). Ensure that the plastic washers (2) are fitted.
- Fasten the DNC-board with cylinder bolts.
- Plug-in the relay.

Assembly simplification:

First plug-in all cables, then screw the pc-board tight.

Cable:

1. Attach 16 - 12-pole cable (1) to CPU and DNC-board.
2. Attach 5-pole cable (2) to CPU and DNC-board.
3. Attach 2-pole cable (3) from mains board to DNC-board.
4. Remove the 2-pole cable (4) from the cable clip and attach to the DNC-board.

Note:

On 5-pole cable, the side with the 6 cores on the plug must be attached to the CPU, and the side with the 5 cores on the plug must be attached to the DNC-board. Pin 3 of this cable may not be wired (Pin 3 is connected with Pin 1, as standard, for this reason, the CPU side has 6 cores). Via Pin 3, the "Start" pulse for the main spindle is transmitted, that comes with the programming of M06/T/0 after the issuance of the intermediate stop (danger of injury during manual tool change).



## G66 RS 232 Operation (V24/20mA - Operation)

G66 function is like G64, G65 a pure switch function for the operation of the interface RS 232. RS 232 is an internationally standardised interface.

It is an output/input for information. Via this interface information (data) can be transferred into an unit which has the same interface RS 232 C.

The data are sent via a connecting cable. This connecting cable has to be produced by a specialist for the respective unit. The information for the manufacture are to be found in the wiring diagrams of the manufacturer of these units.

### Examples Using RS 232:

- Connection of a computer system
- Connection of a printer
- Connection of the EMCO-TRAINER
- Connection of a perforated tape reader and a perforated tape puncer.

Survey RS 232-Operation


Examples for transmission of data:

<u>Transmission from perforated tape into computer:</u>	<u>Transmission from perforated tape to machine:</u>
<ul style="list-style-type: none"> <li>- Switch to CNC-operation</li> <li>- Put in perforated tape</li> <li>- Start tape reader</li> </ul>	<ul style="list-style-type: none"> <li>- Put in perforated tape</li> <li>- Switch to CNC-operation</li> </ul>
<p>G66</p>	<p>G66</p>
<p>INP The read-out indicates. <math>\begin{matrix} \text{N} &amp; \text{G} &amp; \text{X} &amp; \text{Z} &amp; \text{FK} &amp; \text{M} \\ \text{M} &amp; \text{I} &amp; \text{R} &amp; \text{LT} &amp; &amp; \text{O} \end{matrix}</math></p> <p>A</p> <p>ASCII = American Standard Code of Information Interchange</p>	<p>INP The read-out indicates: <math>\begin{matrix} \text{N} &amp; \text{G} &amp; \text{X} &amp; \text{Z} &amp; \text{FK} &amp; \text{M} \\ \text{M} &amp; \text{I} &amp; \text{R} &amp; \text{LT} &amp; &amp; \text{O} \end{matrix}</math></p> <p>A</p>
<p>INP The read-out indicates:</p> <p><math>\begin{matrix} \text{N} &amp; \text{G} &amp; \text{X} &amp; \text{Z} &amp; \text{FK} &amp; \text{M} \\ \text{M} &amp; \text{I} &amp; \text{R} &amp; \text{LT} &amp; &amp; \text{O} \end{matrix}</math></p> <p>A LO</p>	<p>INP The read-out indicates: <math>\begin{matrix} \text{N} &amp; \text{G} &amp; \text{X} &amp; \text{Z} &amp; \text{FK} &amp; \text{M} \\ \text{M} &amp; \text{I} &amp; \text{R} &amp; \text{LT} &amp; &amp; \text{O} \end{matrix}</math></p> <p>A LO</p>
<p>(LO=LOAD) The program is being transferred. At the end of the transfer operation the read-out indicates N00.</p>	<p>RUN Start tape reader, the program is transmitted.</p>

## RS 232C Connection Cable for COMPACT 5CNC and F1-CNC

The V24 Interface is used with this cable. The machine (COMPACT 5 CNC/F1-CNC) is thus set at 300 baud.

### Pin occupancy of the cable (standard) for V24 Interface



COMPACT 5 CNC  
F1-CNC

25-pin RS 232 plug for peripheral device

The only "handshake line" of the COMPACT 5 CNC and F1-CNC is intended for the "request to send" (RTS) signal. The RTS core is connected to pin 5 of the 25-pin plug. The Interface of the COMPACT 5 CNC/F1-CNC does, however, function without the request to send signal. (A handshake line is a control line for the data flow. It releases or stops a transmission)

### Notes in the event of problems with Interface RS 232C

Since the COMPACT 5 CNC and the F1-CNC do not depend on a handshake line, you can presume that the transmission and reception mode will be carried out (simple design of the Interface on COMPACT 5 CNC and F1-CNC).

#### Trouble-shooting in the event of problems

1. Check whether the peripheral device actually has a RS 232 Interface. That is a BIT serial Interface and not a BYTE serial, such as Centronics or IEEE 488.
2. Check whether the V24 or 20 mA Interface on the peripheral device is active.

Pin occupancy COMPACT 5 CNC/F1-CNC

Pin occupancy RS 232 Interface:

<u>V24 Interface</u>	
Plug Pin B	Transmit
A	Receive
C	GND
D	Request to send

<u>20 mA Interface</u>	
Plug Pin F	- 20 mA
G	+ Transmit
H	- Receive
J	+ 20 mA

Plug Pin E	Baud rate	open	300 bd.
		to GND	110 bd.

If you use the 20 mA connection, open bow contact H/J and note the baud setting.

- 110 or 300 baud rate: Check setting on peripheral device and COMPACT 5 CNC or F1-CNC.


With the EMCO cable, the COMPACT 5 CNC/F1-CNC is set at 300 baud (Pin E not with Pin C - GND - with bow contact).

- The Interface of data receiver (e.g. printer, PC ...) must be equipped with a buffer memory (due to the lack of handshake signals of the COMPACT 5 CNC/F1-CNC).
- Check the pin occupancy TRANSMIT and RECEIVE.

Transmit: From COMPACT 5 CNC/F1-CNC to peripheral device (the peripheral device is the receiver).

Receive: From the peripheral device to COMPACT 5 CNC/F1-CNC (the peripheral device is the transmitter).

Pin occupancy of the cable:



COMPACT 5 CNC  
F1-CNC

Peripheral device

- Check whether your peripheral device is operating without the cabling of the handshake line or if the handshake lines must be functionally disconnected (bow contact, DIL-switch, etc.)

7. Transmission from COMPACT 5 CNC/F1-CNC to the peripheral device: the COMPACT 5 CNC/F1-CNC transmits 7 bit ASCII code. The eighth bit is intended as parity bit, which is not, however, transmitted.

In the event of reception, a parity bit can be transmitted, although it is not required and is disregarded by the COMPACT 5 CNC/F1-CNC.

At 110 baud, one start bit and two stop bits are transmitted.


At 300 baud, one start bit and one stop bit are transmitted.

### Peripheral device remarks, control lines

The control line connections differ according to the device. Please note the instructions.

- Where the peripheral device requires control lines for operation, the clear to send (Pin 4) can be connected with the request to send (Pin D) of the COMPACT 5 CNC/F1-CNC.


The second possibility would be, to bow connect Pin 4 and Pin 5.



- There are also devices which require the additional signal "Data Terminal Ready". This signal can be generated by bow connection of Pin 6 and 20.

#### Example of a connection:

4/5 bow connected  
6/20 bow connected  
C/E bow connected (setting at 110 baud).



## Video Connection, TV-Connection Interface RF232

### 1. Mounting possibilities of Videoprint

- 1.1. COMPACT 5 CNC with electrical serial numbers A6A/B/C 1o5.000 / 000 - 049:

**No connection possibility!**

- 1.2. COMPACT 5 CNC with electrical serial number A6A/B/C/F/G/H/N 1o5.000 / 050 - 618:

Means: **Computer board A6C 114-002**



+

**Videoprint (Ref.No. 26o 2oo)**

- 1.3. COMPACT 5 CNC with electrical serial number A6A/F/G/H/N 1o5.000 / 619 upwards:

Means: **Videoprint Ref.Nr. 26o 2oo**  
(The computer board A6C 114 002 is mounted)

### 2. Equipment of Videoprint (Ref.No. 26o 2oo)



- 1 Videoboard (A6A 115 000)
- 2 Cable RS 232 (A6Z 2o1 000)
- 3 Coupling plug RS 232 (ZEL o3 0o12)
- 4 TV-cable (A6Z 2o2 000)
- 5 TV-coupling plug (ZES 15 1oo6)
- 6 Video cable (A6Z 2o3 000)
- 7 Spacing bolt (ZBO oo 6256)
- 8 Washer (ZSB 51 o315)
- 9 Key for tightening cable couplings (A6Z 2oo o1o)

### 3. Necessary means for the connection of TV/monitor etc.

#### 3.1. TV-connection:

- Standard antenna cable (co-axial approx. 60 - 75  $\Omega$ )
- Plug for TV-apparatus

#### 3.2. Video connection:

- Video cable with cinch plugs


#### 3.3. RS 232:

- 4 or 5-pole protected cable (4 resp. 5 x 0,14 mm<sup>2</sup>)



### 4. Mounting the cables

Insert the cables through the bores.  
Fix the cables with the counter nuts  
and plug them to the video print.


#### Electrical control unit A6A/B/C



#### Electrical control unit A6F/G/H/N



## 5. Setting language and frequency on the video board



Language and frequency are set with the code switch (1).

### 5.1. Frequency setting:

50 Hz: switch 2 "ON"

60 Hz: switch 2 "OFF"


Illustration shows position for 50 Hz

5.2. Languages are set with switch 3 and 4.

### Combinations

Language	Switch 3	Switch 4
German	OFF	OFF
English	OFF	ON
French	ON	OFF
Spanish	ON	ON

5.1



5.2




Illustration shows switch positions for German.

### Note:

The first switch is without function.

The change of language appears when the machine is switched off and on.

### TV-Characteristic

UHF receiving unit : frequency between 500 and 700 Megahertz  
Transmitter frequency must be adjusted.

### Monitor-Characteristic

Equipped for receiving BAS resp. COMPO-SIT signals.

## 6. Interface RS 232

For connection of paper tape punchers, paper tape readers, printers, computer systems, etc.

For the connection of the several devices you must know the PINNING!



Pinning of COMPACT 5 CNCPin occupancy RS 232 Interface:

20mA Interface	
Plug Pin F	-20mA
G	+ Transmit
H	- Receive
J	+20mA

V24 Interface	
Plug Pin B	Transmit
A	Receive
C	GND
D	Request to send

Plug Pin E	Baud-Rate left open	300bd.
	conn. to GND	110bd.

Examples RS 232

a) 20 mA Interface:

Connection to Teletype ASR 33  
(Duplex operation, 110bd.)


COMPACT 5 CNC		TTY	
Pin J	Receive +	TB 7	
H	Receive -	TB 6	
G	Transmit +	TB 4	
F	Transmit -	TB 3	
E } C }		jumpered	
GND		GND Shield connected to ground	

b) V24 Interface:

Connection to printer, paper tape recorder/paper tape puncher etc.

COMPACT 5 CNC

Accessory



Note: Parity bit is not used.

Note: If pins H and J are not used they must be jumpered.

RS 232 Connection / Some Tips

Connection with tape readers, punchers, computers, etc.

Pinning and cable type of COMPACT 5 CNC see page 4/5.

The plug for the RS 232 Interface of the COMPACT 5 CNC is delivered with the Videoprint.

Connection:

Either the producer of the tape reader, puncher, computer, etc. makes the connection or he tells you the pinning of the device so that you yourself can make the connection.

Examples:Possibility 1:

You send to the producer X the RS 232 plug of the EMCO COMPACT 5 CNC and the pinning description (page 4/5). The producer X makes the cable to plug the COMPACT 5 CNC with the tape reader, puncher, computer, etc.

Possibility 2:

You ask the producer of the paper tape reader, puncher, computer, etc. for the pinning of his device and mount the plugs yourself.


Activating RS 232:

RS 232 is activated via G66. G66 does not enter the memory, it is a switching function.

Examples:

● Transmission from paper tape to memory of COMPACT 5 CNC  
(With "Request to send" signal)

- Switch to CNC-mode (memory must be empty)
- Insert paper tape
- Start paper tape reader



1. Program G66

2. Press **INP**

On the display appears 

o o o o o o
A

  
(A is the abbreviation for ASCII = American Standard Code for Information Interchange)

3. Press **INP**

The display shows 


o o o o o o
A L O

  
(LO = LOAD)  
The program is transferred. At the end of the transfer the display shows 

N	OO
---	----

● Transmission from paper tape to COMPACT 5 CNC  
(without "Request to send" signal)

- Insert paper tape
- Switch to CNC-mode



1. Program G66

2. Press **INP**

The display shows 

o o o o o o
A

3. Press **INP**


The display shows 

o o o o o o
A L O

4. Start paper tape reader (transmission begins)

Transmission from COMPACT 5 CNC to paper tape  
(with or without "Request to send" signal)

- Switch to CNC-mode
- Insert paper tape
- Start paper tape puncher



1. Program G66

2. Press **INP** Display shows 

A
---

3. Press **FWD.** Display shows 

A	S	A
---	---	---

  
(SA = SAVE)

The paper tape is punched.

Data formats COMPACT 5 CNC  
Software A6C 114 004

123456789012345678901234567890 31 32

```

% CR LF
....N'.G'...X:'....Z.'..F'..H. CR LF
....00.24..... CR LF
....01.00.-5999..32760..... CR LF
....02.01....01,....12.499.... CR LF
....03.02.-1000.-.1000..09.... CR LF
....04.03...200...200.199.... CR LF
....05M99.I..00.K..200..... CR LF
....06.04....10..... CR LF
....07.21..... CR LF
....08M06..1222.-10000I.01.... CR LF
....09.78...100.-.2000K120..20 CR LF
....10.73.....-.100.100.... CR LF
....11.81......02.400.... CR LF
....12.82.....-10200.100.... CR LF
....13.83......30..09.... CR LF
....14.85......2000.120.... CR LF
....15.89......2300.200.... CR LF
....16.86.-.100...3000..50.100 CR LF
....17.88...200...300.200..05 CR LF
....18.84.-1000.-.2000.499..26 CR LF
....19.90..... CR LF
....20.91..... CR LF
....21.92...100...200..... CR LF
....22.94..... CR LF
....23.95..... CR LF
....24.33.....-.5000K100.... CR LF
....25M00..... CR LF
....26.27......L.02.... CR LF
....27.25......L.98.... CR LF
....28M03..... CR LF
....29M05..... CR LF
....30M08..... CR LF
....31M09..... CR LF
....32M17..... CR LF
....33M22..... CR LF
....34M23..... CR LF
....35M98....02....03..... CR LF
....36M30..... CR LF
...M

```

Space ASCII 32

ASCII 96


CR Carriage return ASCII 13

LF Line feed ASCII 10

When programs are received, the data format must be fully retained, otherwise the programs will not be correctly stored.

You can also obtain the data format by printout of a punched tape.

Service Information Turret Toolpost



1. For better mounting the turret board connection, the power supply board has been redesigned: F1A(V,C) 111 000
2. The two-pole cable for power supply board has been modified.

Point 1


Power supply board F1A(V,C) 111 000

On the power supply board you find a plug contact (1) and a clamping strip.

Point 2

Turret toolpost

The two-pole cable supplied with the turret toolpost has a plug.




Connection

1. Power supply board F1A(V,C) 111 000

It is mounted in the machine.  
Cable with plugs

Plug the two-pole cable to plug (1).



2. Power supply board F1A(V,C) 111 000

Your cable has no plug.

Clamp the cable to connecting strip (2).

3. Power supply board old version, but new cable

Remove plug and make connections as described in the instructions provided with the turret toolpost.